

# ELUX

# FINEO


OPEN POD KIT



User Manual



# ILLUSTRATION



## SPECIFICATIONS

Dimension (with Pod): 110.2\*22.5\*13.5mm

Battery Capacity: 650 mAh

Pod Capacity: 2 ml

Charging: Type-C

## PACKING LIST

ELUX FINEO battery \* 1

1.0 $\Omega$  FINEO Refillable Pod \* 1

0.6 $\Omega$  FINEO Refillable Pod \* 1

User Manual\* 1


# INSTRUCTIONS

## 1. Turn On/Off

Insert and take out the pod of the device 3 times in 2 seconds to turn on/off. The motor will vibrate once and the light will flash 3 times as a hint.

## 2. Pod Filling

- Take out the empty pod and open the side filler plug.
- Put the nozzle of the e-liquid bottle into the filling port to fill with the e-liquid.
- Put the filler plug as soon as possible to avoid leakage.
- **SIT THE POD 5 MINUTES BEFORE USE.**



## 3. Vaping

- Insert the filled pod into the device, and the motor will vibrate once and the light will flash once quickly.
- Draw to vape.

**Attention:** Please change a new pod when there's unexpected taste occurs.

## 4. Pod Replacement

Take out the used pod from the device, and install a new one, the light will flash once quickly when taking the pod off.

**PLEASE SIT THE FILLED NEW POD FOR 5 MINUTES BEFORE INSTALLING IT TO DEVICE.**

## 5. Light Indication

- When the battery capacity is at high level, the light will flash in green during vaping. When the battery capacity is at middle level, the light will flash in blue during vaping. When the battery capacity is at low level, the light will flash in red during vaping.
- The light will flash twice when the vaping time is over 8 seconds, and the device stops output.
- The light will flash 10 times when the device voltage is too low, and the device stops output.
- The light will flash 5 times when the short-circuit occurs.
- The light will flash 7 times when the open-circuit occurs.

## 6. Vibration Indication

The motor will vibrate in different statuses to indicate different working modes. When it vibrates during vaping it is a charging hint.

## 7. Charging

Charge the device with a type-C charging cable, the motor vibrates once as a hint when connecting to the power supply and the light is on. The light will flash 4 times when taking the charging cable off and will go out when the charging is done.

## ATTENTION

1. Please keep the device away from children.
2. Do not disassemble the pod.

## WARNING

**Always keep the device away from children.**

- Don't open the vaping device and don't attempt to repair the device yourself. Disassembling the device may damage it or may cause injury to you.
- Do not cover the Device with items such as newspapers, tablecloths, or curtains, and do not use this Device on soft support such as bedding, blankets, etc. It may cause burns and other injuries if the battery leaks or overheats during the night.
- Do not use your Device near sinks or other wet locations;
- Do not expose this Device to rain or moisture.
- Do not expose your device to extreme heat or cold. This may result in a risk of battery damage, other injury, or property damage.
- Do not leave the vaping device in direct sunlight or near heat sources.
- Do not use the vaping device near flammable liquids or gases.

## DISPOSAL

- Dispose of the packaging and the device shall always be in accordance with national and local laws and regulations.
- Never put the vaping device on fire. The built-in lithium-ion battery may burst or explode.