



ELUX Legend Prime

Refillable Disposable



User Manual



SPECIFICATIONS

Dimension (with Pod):

101*21.7*21.7mm

Battery Capacity: 600 mAh

Charging: Type-C

Pod Capacity: 2 ml

PACKING LIST:

1*ELUX LEGEND PRIME 5000 Battery


1*ELUX LEGEND NIC SALTS 10ml

1*User Manual

INSTRUCTIONS

1. Pod Filling

- A. Open the side filler plug on the pod.
- B. Put the nozzle of the e-liquid bottle into the filling port to fill with the e-liquid.
- C. Put the filler plug back as soon as possible to avoid leakage.



* **SIT THE DEVICE 5 MINUTES BEFORE USE.**

2. Vaping

- A. Take off the sealing bar, and draw to vape.
- B. The indicator will gradually light up and stop when it reaches its brightest brightness. When you stop smoking, the indicator will gradually turn off from the brightest until it goes out completely.

3. Light Indication

- A. The light will flash twice when the vaping time is over 8 seconds, and the device stops output.
- B. The light will flash 10 times when the device voltage is too low, and the device stops output.
- C. The light will flash 5 times when the short-circuit occurs.
- D. The light will flash 7 times when the open-circuit occurs.

4. Charging

- A. Charge the device with a type-C charging cable, the indicator will turn on and off gradually while charging. When the device is fully charged, the indicator will stay green.
- B. The indicator shows green when the battery level is over 80%; The indicator shows blue when the battery level is between 40%-80%; The indicator shows red when the battery level is between 0%-40%;

- C. Pull out the type-c charging cable, the indicator will flash 3 times.

Note: If there is no pod installed into the device, the indicator will keep flashing after connecting to the power source.

ATTENTION

1. Please keep the device away from children.
2. Do not disassemble the device.

WARNING

Always keep the device away from children.

- Don't open the vaping device and don't attempt to repair the device yourself. Disassembling the device may damage it or may cause injury to you.
- Do not cover the Device with items such as newspapers, tablecloths, or curtains, and do not use this Device on soft support such as bedding, blankets, etc. It may cause burns and other injuries if the battery leaks or overheats during the night.
- Do not use your Device near sinks or other wet locations;
- Do not expose this Device to rain or moisture.
- Do not expose your device to extreme heat or cold, This may result in a risk of battery damage, other injury, or property damage.
- Do not leave the vaping device in direct sunlight or near heat sources.
- Do not use the vaping device near flammable liquids or gases.

DISPOSAL

- Dispose of the packaging and the device shall always be in accordance with national and local laws and regulations.
- Never put the vaping device on fire. The built-in lithium-ion battery may burst or explode.